

Registered office:

Caleb Components Limited,  
Block 6 Grazebrook Industrial Park  
Peartree Lane  
Dudley  
DY2 0XW  
UK

Tel: 0044 (0)1384 453955

Email: [sales@calebcomponents.com](mailto:sales@calebcomponents.com)

Shop Online: [www.springfasteners.co.uk](http://www.springfasteners.co.uk)



## How to correctly fit Split Cotter Pins...

### Here is some helpful information when it comes to fitting Split Cotter Pins.

Firstly, make sure the Cotter Pin is the correct size.

These parts are listed by the hole size they're fitting in to. For example, a **2mm cotter pin**, will suit a **2mm hole**. Cotter Pins are always made undersize on the diameter so it can be inserted into the hole.

These parts are very easy to install.

Insert the Cotter Pin into the hole by inserting the legs first. Push the legs all the way through until the head of the cotter pin sits on top of the hole.

Then bend each leg backwards in opposite directions to ensure a firm & secure connection.

We strongly recommend using the cotter pin only once, as once the legs have been bent, the cotter pin is then distorted, making it more difficult to reuse the pin.

Require further assistance? Feel free to get in touch using the contact details above.

